Part Number: CAI-CR001B, CAI-CR001R

Part List:

Intake pipe	1 Piece
Coupler	1 Piece
Rubber hose	1 Piece
Clamp	3 Pieces
Air filter	1 Piece
Universal bracket	1 Set

Note: Disconnect the negative battery terminal before starting this installation. The installation of this cold air intake does require mechanical skills. Removal of the front bumper requires loosening

1- Remove the bolts that securing the stock air filter box, loosen the clamps on the stock rubber intake tube.

2- Remove the PVC hose from the stock intake system and engine.

3- Disconnect the IAT sensor harness, remove the IAT sensor from the intake system.

4- Remove the stock rubber intake duct and air filter box from the vehicle by pulling upwards.

5- Install the reducer coupler with 2 clamps onto the throttle body, tighten the clamp on the throttle body.

6- Install the stock IAT sensor into the grommet on the intake pipe.

7- Insert the intake pipe into the reducer coupler on the throttle body. Semi-tighten the clamp.

8- Install the rubber hose from the intake pipe to the engine.

9- Install the air filter onto the open end of the intake pipe. Semi-tighten the clamp on the filter neck.

10- Reconnect the IAT sensor harness.

11- Ensure that the air filter is not touching any part of the vehicle. Position the inlet pipe for best fitment. Be sure that the pipe or any other component is not in contact with any part of the vehicle. Tighten the clamps at the throttle body and reducer coupling. Tighten the bolt on the intake resonator mounting bracket. Check for proper hood clearance. Re-adjust pipes if necessary.

12- Installation complete.

For the idea of the Bracket Installation(Not for all intakes), please visit http://www.youtube.com/watch?v=IMIXVYGW2Zk.